



HOW TO INSTALL **GRIPSSS** HOCKEY STICK GRIP TAPE



- 1**
- Pull the protective film off of the top cap and align the cover over the butt end of the stick.



- 2**
- Once aligned on the butt end fold the flaps over and apply pressure to stick the top cap onto the shaft of the stick.



- 3**
- Unwrap the GRIPSSS grip tape.
 - Find the thin end of the tape and remove part of the protective film.
 - Line up the straight edge of the GRIPSSS grip tape with the top the top edge of the stick.



- 4**
- Apply pressure to the GRIPSSS to attach to the stick, and begin to wrap the grip all the way around the stick.
 - Stop when you reach the thin edge.
 - Continue to wrap the stick but on an angle downwards while overlapping the GRIPSSS tape ¼ inch (about ½ cm).



- 5**
- Continue wrapping down your stick until the GRIPSSS tape grip becomes thinner again



- 6**
- Begin to overlap the GRIPSSS tape at the thinner portion, so the bottom edge is straight across the stick and all the way around and you run out of grip tape.



- 7**
- At the bottom of the wrapped GRIPSSS tape, wrap a single piece of electrical tape covering half of the GRIPSSS tape and half of the hockey stick.



- 8 AND 9**
- Remove the adhesive backing of the finishing strip and place it overtop of the electrical tape.

